



1. WiFi only supports 2.4GHz network (802.11b/g/n). 5G network is not available.
2. Only supports unidirectional/unipolar circuits, not compatible with mutual control switches.
3. Need a neutral wire. (Please do not install if there is no neutral wire in the cassette).
4. Basic electrical wiring knowledge or experience is required, or please consult a professional electrician.
5. Never connect the neutral wire and the live wire reversely
(Otherwise the electrical appliances will not work).
6. Long press the ON / OFF button to restore the device to the factory default settings. Do this only when you are sure you want to delete all settings. (This operation will change the status of network distribution).
7. A screwdriver , a test pencil and other tools are needed.

Smart switch*1, Switch cover*1, Screw*2, Wire nuts*4, User manual*1 Mark labels*1
Before installation, please confirm whether the accessories are complete. If there are incomplete accessories or other problems, please email us or contact us on Amazon or via email on the after-sale card. (In addition, product styles and designs may be improved, and the accessories may be changed in due course).

Specifications

Type	Smart PIR Sensor Switch
Model	
Power supply mode	Neutral+Live Wire
Rated Current	15A(Max)
Rated Voltage	
Rated Power	1650W(MAX)
Wireless Frequency	2.4GHz
Wireless Standard	IEEE802.11 b/g/n

Technical drawing of the PIR sensor switch. The front view shows a rectangular device with a light sensor at the top and a PIR sensor below it. Dimensions include a total width of 41.6mm, a height of 152mm, and a mounting bracket width of 28.1mm. The side view shows the device's profile. Labels indicate the Light Sensor (works when brightness is less than 15lux), PIR Sensor, and Indicator light.

Indicator light meaning

Indicator	Status	Description
ON/OFF Button		
Blue light	Flash Rapidly	Ready for connection (Default Mode Only)
Blue light	Flash Slowly (once every 1s)	Ready for connection (AP Mode Only)
Blue light is on	ON	Turn the light on
Green light is on	ON	Turn the light on
Blue light	Flash Slowly	No Internet

- Cut off the power before installation
- Please use it only when it's installed with RCD or current leakage protector at home
- A neutral wire is needed to power the switch.

The diagram illustrates the connection of a load to a power source. On the left, a power source (represented by a battery symbol) is connected to a switch. The switch has two positions: 'ON' and 'OFF'. A red arrow labeled 'Load' points to the switch. The switch is connected to a 'Line' terminal. A black arrow points to the right, where a switch is shown in the 'ON' position. The switch is connected to a 'Line' terminal. The switch has two positions: 'ON' and 'OFF'. A red arrow labeled 'Load' points to the switch. The switch is connected to a 'Line' terminal.

Usually:
 White represents the neutral line.
 Black represents the fire line.
 The green or a single bare copper wire represents the ground wire.
The above content is for reference only and cannot be used as a standard.

Usually:
White represents the neutral line.
Black represents the fire line.
The green or a single bare copper wire represents the ground wire.
The above content is for reference only and cannot be used as a standard.


1. Connect the mobile phone to the indoor WiFi and download the APP "Smart Life" that controls the switch (please scan the QR code below to download).



Find out “Smart Life” app in Apple app store, Google Play, or scan the QR code bellow and install it. The free app “Smart Life” is compatible with mobile devices the support IOS8.0 above, Android 4.4 above.

Enter the register interface, input the email address/phone number for getting the verification code to register an account. Please just login if you already have a Smart Life account.

green wire on the switch-----connect with ground line,
white wire on the switch-----connect with neutral line,
black wire on the switch-----connect with fire line,
red wire on the switch-----connect with load line.




After the installation is complete, turn on the circuit breaker. Then you can control the switch by pressing the button/touching.


This product has two network connection modes: EZ mode and AP mode. Note: Each mode only lasts for three minutes in the state of "to be connected". If the connection cannot be completed within three minutes, you need to press and hold the setting again to do the connection one more time (switching method between the two modes: press and hold the switch key for 5-10 seconds until the indicator light is on).

EZ mode: After long press, the switch indicator flashes once every 0.3 seconds, it shows that the switch is in the state of EZ mode, in this state, it supports APP "Auto Scan" mode and WiFi quick connection mode in "Add Manually" block. (Supports simultaneous connection of multiple switches).


AP mode: After long press, the switch indicator light flashes once per second, it shows that the switch is in the state of AP mode, in this state only the hotspot distribution network mode (compatible mode) in the APP “Add Manually” is supported. (Only supports one switch connection).



EZ mode network configuration method ②: Open the smart life APP→My Home interface→click the plus icon in the upper right corner→Add manually→select the electrical switch (WiFi)→set WiFi password→Next→confirm that the switch is in the EZ mode→search device →Done



AP mode network configuration method: open the Smart Life APP→My Home interface→click the plus icon in the upper right corner→manually add→select the electrical switch (WiFi)→set the WiFi password→click the option on the upper right corner→select AP Mode → confirm that the switch is in AP Mode→Next→Go to connect→automatically switch to the wireless LAN interface of the mobile phone and select the wireless LAN signal named SmartLife-XXXX→back to the smart life APP interface to automatically complete the network configuration →Done.



1. Do not modify or disassemble the product by yourself.
2. Do not hit the equipment with sharp objects.
3. The product is a household device, do not install it on industrial environment.
4. Do not install the switch in a metal house or a place that may shield the wireless signal.
5. The live wire and neutral wire of the switch must be connected via a same leakage protector, otherwise it is easy to cause tripping and other phenomena.
6. After installation, please fix the panel firmly before powering on the switch. Live operation is strictly prohibited.
7. The mobile phone control is related to the strength of the WiFi signal connected to the switch. It is recommended to use a router with a strong signal.
8. There is an upper limit on the number of smart products controlled by ordinary routers. If it is overloaded, it will automatically squeeze out smart products with relatively weak signals. (Generally, the upper limit is 10-12, including computer phones, etc).
9. If you do not install and use it for a long time, please store it in a dry environment at -10°C ~ -40°C , and keep it out of the reach of children.
10. Provide one-year warranty.