

User Guide



MODELO: S186

I. Pairing the SOS band

· Before starting pairing

1. Turn on the alarm host and enter the pairing state.
2. Ensure the alarm host is disarmed.
3. Remove the battery insulation.

· Pair with the alarm host

1. Go to the alarm host, select the Urgent category, and ready to pair the SOS band.
2. Press the SOS button to send a signal to complete the pairing.

If pairing with the alarm host fails, put the alarm host back into pairing mode and try again.

If the band is paired with the alarm host, it will appear in the alarm host's device list.

II. Specification

Standby currents: $< 3\mu\text{A}$

Alarm current: $\leq 15\text{mA}$

Working temperature: $-10^{\circ}\text{C} \sim +50^{\circ}\text{C}$

Wireless parameters: 433MHz

Wireless transmitting Distance: $< 80\text{m}$ (open area)

Case material: ABS plastics

Product size: $245 \times 43 \times 16\text{mm}$

