

LÁPIZ LIMPIADOR FTTH DE UN SOLO CLICK

Y031

> DESCRIPCIÓN

El Cleaner SC es un dispositivo de alto rendimiento diseñado para limpiar las caras terminales de los férulas de conectores SC, FC, ST y E2000 con pulido UPC y APC.


> ADVERTENCIAS

- No intente desmontar el dispositivo, ya que esto podría dañarlo.
- No reutilice el paño de limpieza, ya que perdería su capacidad de limpieza.
- No toque el paño de limpieza, ya que esto provocaría contaminación.
- No tire del paño de limpieza; manipule únicamente el cuerpo del dispositivo.
- No utilice el limpiador cuando el paño esté agotado, ya que esto podría dañar el conector.
- No exponga el dispositivo a la luz solar directa, a altas temperaturas ni a una humedad elevada.
- La tapa de la guía debe permanecer cerrada siempre que no se esté utilizando el dispositivo.


> APLICACIÓN

<Connector inside adaptor>

- 1.Remove Guide Cap from the device.




- 2.Insert tip of cleaner into MU/LC Adaptor.



Note: This drawing shows only SC, but this product can clean FC, ST and E2000 too.

- 3.Push the Outer Shell to start cleaning the SC connector end face. A "click" sound indicates end of cleaning process. Close the cover after use.




Be careful not to slant the Cleaner SC while inserting into the adaptor.

Do not overly exert force during insertion as this may cause damage to both the connector and the Cleaner SC.


If pushing Outer Shell is inhibited, remove Cleaner SC from adaptor and ensure that there is no sizeable debris inhibiting the cleaning process.

<Connector plugs alone>

- 1.Open the Cover on the Guide Cap.




- 2.Insert MU/LC connector into the Guide Cap.



Note: This drawing shows only SC, but this product can clean FC, ST and E2000 too.

- 3.Push the Outer Shell to start cleaning the SC connector end face. A "click" sound indicates end of cleaning process. Close the cover after use.





Be careful not to slant SC connector while inserting into the Guide cap.

Do not overly exert force during insertion as this may cause damage to both the connector and the Cleaner SC.

If pushing Outer Shell is inhibited, remove the Cleaner SC from adaptor and ensure that there is no sizeable debris inhibiting the cleaning process.

> CONSTRUCCIÓN DEL DISPOSITIVO





	View of Indicator	View of the Nozzle end
Full	Cloth (White)	Tip(Black)
Little	Cloth (White)	Slide Cloth (White)
Empty	Red	Tip(Black)
		No Cloth (Black)

Standard Mode

No.	Part Name	Function
A	Tip	Lead the cleaning cloth to the optical connector end face.
B	Nozzle	Lead tip to the optical connector end face.
C	Lock Button	Push the button to extend and contract the nozzle.
D	Outer Shell	Push the outer shell to clean the connector.
E	Guide Cap	Acts as dust cap or cleaning adaptor for connector plug.
F	Indicator	Provides indication of remaining cleaning cloth.

Extended Mode

Push Lock Button

Pull Nozzle

Pull Nozzle while Pushing lock button.