材质：128g双铜纸　双面黑白印刷, 风琴折

尺寸(Size)：88 X 88 mm

front side
正面

HAVIT



PS100 PROJECTOR SCREEN

PRODUCT MANUAL

OPERATION MANUAL

1. Opening the tripod
2. Slightly raise the stand
3. Swivel the screen to its horizontal position



1

back side
反面

4. Unroll the screen and attach it to the bracket hook
5. Raise the stand
6. Locate the handle at the required height



2

7. Unroll the screen to its maximum height
8. To fold the screen . lift the handle and proceed in reverse order



3